

PART 1 - GENERAL

1.1 SUMMARY

- A. This Section includes electric traction freight elevators. Conventional gearless equipment should be employed where passenger capacity needs, or material movement needs, exceed those offered within electric traction freight product lines.

1.2 DEFINITIONS

- A. Definitions in the latest version of ASME A17.1 apply to work of this Section.
- B. Defective Elevator Work: Operation or control system failure, including excessive malfunctions; performances below specified ratings; excessive wear; unusual deterioration or aging of materials or finishes; unsafe conditions; need for excessive maintenance; abnormal noise or vibration; and similar unusual, unexpected, and unsatisfactory conditions.
- C. Service Elevator: A passenger elevator that is also used to carry freight.
- D. Reference to a device or a part of the equipment applies to the number of devices or parts required to complete the installation.

1.3 PERFORMANCE REQUIREMENTS

- A. General: Refer to Section 14 20 00, Vertical Transportation, General.

1.4 QUALITY ASSURANCE

- A. Regulatory agencies: elevator design, materials, construction clearances, workmanship, and tests shall conform to the requirements of the codes and regulations listed in Section 14 20 00, Vertical Transportation, General.
- B. Welding: Welding shall be performed in accordance with the requirements of AWS or CWB. Welders shall produce evidence of current certification by AWS or CWB.
- C. Requirements of Regulatory Agencies
 - 1. Installer shall obtain and pay for all necessary permits and perform such tests as may be required for acceptance and approval of elevators by jurisdictional agencies.
 - 2. Installer shall notify the proper inspectors to witness required testing.
- D. Factory Visit:
 - 1. The Installer shall provide for the costs of up to three Port of Seattle representatives to visit the factory where the elevators are being manufactured, per contract, per unit type.

2. Installer shall not ship the elevator without the approval of Port of Seattle's representative after the conclusion of the factory visit.

1.5 SUBMITTALS

- A. Refer to Section 14 20 00, Vertical Transportation, General.
- B. Product Data:
 1. Submit manufacturer's product data for each product and material.
 2. Indicate manufacturer, trade names, and model numbers, components, arrangement, optional and accessories being provided.
 3. Include applicable literature, catalog material or technical brochures.
 4. Include material and equipment specifications, sizes, types, dimensions, weights, rated capacities, and performance curves.
 5. Include utility requirements for wiring, piping, and service connection data, motor sizes complete with electrical characteristics.
- C. Shop Drawings:
 1. Include plans, elevations, sections, and large-scale details indicating openings at each landing, machine room/equipment space layout, coordination with building structure, relationships with other construction, and locations of equipment.
 2. Include cab and entrance drawings, including dimensions, finishes and details.
 3. Include large-scale layout of car operating panels and hall fixtures.
 4. Indicate maximum dynamic and static loads imposed on building structure at points of support and maximum and average power demands.
 5. Power Confirmation Information: Include motor horsepower, code letter, starting current, full-load running current, and demand factor.
 6. All shop drawings submitted must be signed and sealed by an Engineer licensed in the state of Washington.
- D. Samples for Initial Selection: For finishes, including finished metals, materials with involving surface treatments, paint, and color selection.
- E. Maintenance Control Programs: within sixty (60) days after notice to proceed, and prior to installation, Installer shall submit detailed equipment specific interim and revenue service Maintenance Control Programs, showing functions to be performed and their scheduled frequency.
- F. Operating and Maintenance Manuals:
 1. Description and sequence of operation of all equipment installed, including operating use for Building Personnel and tenants, as well as system troubleshooting manuals for technicians.
 2. Maintenance instructions and procedures of all vertical transportation equipment installed, including parts lists, for each elevator system.
 3. Lubrication charts indicating all lubricating points and type of lubricant recommended for all equipment.
 4. Complete parts catalogs for all replaceable parts.

G. Tools:

1. The following equipment is furnished upon completion and before final payment:
 - a. The Elevator Contractor provides all the necessary tools, including laptop, hand-held devices, required software and manuals, required to troubleshoot, adjust, synchronize, calibrate, repair, and maintain the vertical transportation systems, as well as perform all necessary procedures to perform all safety tests as required by code and local governing authority.
 - b. Owner's equipment and software is updated regularly to properly troubleshoot, adjust, synchronize, calibrate, repair, maintain and test the vertical transportation systems. All equipment and/or software is of the same version as issued to technicians maintaining the vertical transportation systems.
 - c. The Elevator Contractor provides a backup copy of any software that resides on the troubleshooting tool.
 - d. Upon cancellation of service agreement, the Elevator Contractor provides all updates indicated above.

1.6 JOB CONDITIONS

- A. General: Refer to Section 14 20 00, Vertical Transportation, General.

1.7 DELIVERY, STORAGE, AND HANDLING

A. General:

1. The protection of all equipment and exposed finishes is the responsibility of the Elevator Contractor during delivery, handling, and installation until final acceptance of elevator equipment.
2. The Elevator Contractor replaces damaged materials with new, at no additional cost for material and labor.

- B. Delivery and Storage: It is the responsibility of the Elevator Contractor to properly store and protect all materials in space provided or designated by the Contractor against damage, stains, scratches, corrosion, weather, construction debris and environmental conditions.

- C. Hoisting: All required hoisting and movement of equipment is the responsibility of the Elevator Contractor.

1.8 COORDINATION

- A. General: Refer to Section 14 20 00, Vertical Transportation, General.

- B. Coordinate installation of VT equipment with integral anchors, and other items that are embedded in concrete or masonry for VT equipment. Furnish templates, sleeves, escalator equipment with integral anchors, and installation instructions and deliver to Project site in time for installation.

- C. Coordinate sequence of VT installation with other work to avoid delaying the Work.

1.9 WARRANTY

- A. Manufacturer's Warranty: Manufacturer agrees to repair, restore, or replace elevator equipment that fails due to defective materials or poor workmanship within specified warranty period.
- B. Warranty Period: Twelve (12) months from date of Substantial Completion:
 - 1. The Elevator Contractor guarantees that the materials and workmanship of the apparatus installed by them and any subcontractor, under this contract, is first class in every respect and that they will make good on any defects not due to ordinary wear and tear or improper use, which may develop within one year from the date of final acceptance of all equipment.
 - 2. Manufacturer's warranty to repair or replace defective products or their components in the event of defects within a specified period.
 - 3. Neither the final payment nor any provisions of the contract documents relieve the Elevator Contractor of any obligation provided by law. They shall remedy any defects and pay all expenses for any damage to other work.
 - 4. The warranty as outlined above, for all devices, starts from the date of final acceptance of each device, by the Owner, of all work specified and intended under these contract documents.
 - 5. All other services as required by Section 14 20 00, Vertical Transportation, General.

1.10 MAINTENANCE

- A. General:
 - 1. All maintenance is performed according to the guidelines stated in manufacturer's Maintenance and Operations manuals.
 - 2. Maintenance records for each device, including lubrication logs, check charts, are provided in each control room.
- B. Construction Maintenance:
 - 1. Upon substantial completion of a device, after receiving sign-off from the governing authorities and acceptance from Consultant and/or Contractor, the device may be accepted for service before completion of the entire project.
 - 2. During the Construction Maintenance period, the necessary preventive maintenance is performed on a scheduled basis.
 - 3. Provide the necessary protection of the hoistway entrances and sills, hoistway fixtures, cab interiors and fixtures and car door sills.
 - 4. Replacement or repair of components, due to misuse by others, is the responsibility of the Contractor/Owner.
 - 5. Perform emergency callback service during normal working hours.
 - 6. Include 24-hour-per-day, 7-day-per-week emergency callback service with response time of sixty minutes or less.
- C. Warranty Maintenance:
 - 1. Upon final acceptance of each device, subsequent to receiving acceptance and sign-off from the governing authorities and final acceptance, each device is accepted for full operation.

2. The warranty maintenance period begins for each device when all conditions in the above paragraph are met and will continue for a specified period.
 - a. Warranty Maintenance Period may begin at different times for each elevator.
3. The warranty maintenance program includes the following:
 - a. Monthly examinations, including adjustments, cleaning, and lubrication of equipment.
 - b. 24-hour Emergency Call back service is provided at no additional cost to Owner.
 - c. Replacement of components as required, using only components produced by the original manufacturer.
 - d. Each control room is equipped with a lockable storage cabinet to contain the necessary spare parts. See Specification 01 79 00 for spare parts list.

PART 2 - PRODUCTS

2.1 REFERENCES

- A. Definitions: Terms used are defined in the latest edition of the Safety Code for Elevators and Escalators, ASME A17.1.
- B. American Society of Mechanical Engineers:
 1. ASME A17.1 - Safety Code for Elevators and Escalators.
 2. ASME A17.2 – Guide for Inspection of Elevators, Escalators, and Moving Walks.
 3. ASME A17.5 – Elevator and Escalator Electrical Equipment.
 4. ASME A17.6 – Standard for Elevator Suspension, Compensation, and Governor Systems.
- C. International Building Code (IBC)
- D. National Fire Protection Association (NFPA):
 1. NFPA 70 – National Electric Code.
 2. NFPA 80 – Fire Doors and Windows.
 3. NFPA 101 – Life Safety Code.
- E. Washington Administrative Code, WAC.
- F. American National Standard Institute (ANSI): A117.1 - Accessible and Usable Buildings and Facilities.
- G. 2010 ADA Standards for Accessible Design, Section 407.

2.2 MANUFACTURERS

- A. Subject to compliance with project requirements, provide products by one of the following:
 1. Electric Traction Freight Elevator Systems **(DESIGN TEAM TO CONFIRM WITH PORT OF SEATTLE FOR SPECIFIC PROJECTS):**
 - a. KONE Incorporated

- b. Minnesota Elevator Incorporated
- c. Mitsubishi Electric Corporation
- d. Otis Elevator Company
- e. Schindler Elevator Corporation
- f. TK Elevator
- g. Manufacturer's standard components, including machines, controllers, door equipment, fixtures, and cab enclosures, are approved.

2.3 FIELD CONDITIONS

A. Seismic:

1. Elevator system withstands the effects of earthquake motions determined according to SEI/ASCE 7 and complies with elevator safety requirements for seismic risk Zone 2 or greater in ASME A17.1/CSA B44.
2. The term "withstand" means the system will remain in place without separation of any parts when subjected to the seismic forces specified.
3. Provide earthquake equipment required by ASME A17.1/CSA B44.
4. Provide Alpha-Numeric display if Earthquake Mode is needed.
5. Provide seismic switch required by SEI/ASCE 7.
6. Design earthquake spectral response acceleration short period (Sds): As Shown on Structural Drawings.
7. Occupancy Category: As Shown on Structural Drawings.
8. Project Seismic Design Category: As Shown on Structural Drawings.
9. Elevator Component Importance Factor (Ip): As Shown on Structural Drawings.

2.4 PERFORMANCE REQUIREMENTS

A. Car Speed: $\pm 3\%$ of contract speed under any loading condition.

B. Car Capacity: Safely lower, stop and hold 125% of rated load.

C. Car Stopping Zone: $\pm 1/4"$ under any loading condition.

D. Car Ride Quality:

1. Acceleration and Deceleration: Smooth, constant, and not less than 2.5 feet/second².
2. Sustained Jerk: Not more than twice the rate of acceleration.

E. Noise and Vibration Control:

1. Airborne Noise:
 - a. Measured noise level of elevator equipment and its operation does not exceed 55 dBA inside car under any condition including door operation and car ventilation exhaust blower on its highest speed.
 - b. Limit noise level in the control room relating to elevator equipment and its operation to no more than 80 dBA.
2. Vibration Control: All elevator equipment is mechanically isolated from the building structure.

2.5 ELEVATORS

A. Freight Elevators Description:

1. Elevator Identification: **As detailed on the Contract Drawings.**
2. Capacity: **Design Team to Confirm Capacities.**
3. Class of Loading: Class C1.
4. Contract Speed: **150/200/350/500 fpm.**
5. Machine: Geared or Gearless.
6. Machine Location: Overhead in Machine Room.
7. Floors Served: **As detailed on the Contract Drawings.**
8. Openings: **As detailed on the Contract Drawings.**
9. Minimum Clear Height to underside of canopy: **As detailed on the Contract Drawings.**
10. Entrance Size: **As detailed on the Contract Drawings.**
11. Entrance Type: Power Vertical Bi-Parting.

2.6 MATERIALS

A. Steel:

1. Sheet Steel (Furniture Steel for Exposed Work): Stretcher-leveled, cold-rolled, commercial quality carbon steel, complying with ASTM A366, matte finish.
2. Sheet Steel (for Unexposed Work): Hot-rolled, commercial quality carbon steel, pickled and oiled, complying with ASTM A568/A568M-03.
3. Structural Steel Shapes and Plates: ASTM A36.

B. Stainless-steel:

1. Type 302, 304, or 316 complying with ASTM A240, with standard tempers and hardness required for fabrication, strength, and durability.
 - a. No. 4 Satin: Directional polish finish with grain in the longest direction.

C. Aluminum:

1. Extrusions per ASTM B221; sheet and plate per ASTM B209.

D. Nickel-Silver: Extruded:

- a. C77600 nickel-silver
- b. Hot extruded, temper code M30

E. Fire-Retardant Treated Particle Board Panels:

1. Minimum 3/4" thick backup for natural finished wood and plastic laminate veneered panels, edged and faced as shown, provided with suitable anti-warp backing.
2. Meet ASTM E84 with a flame-spread rating and smoke development rating.

F. Paint Finishes:

1. General:
 - a. Clean exposed metal parts and assemblies of oil, grease, scale, and other foreign matter and factory paint one shop coat of standard rust-resistant primer.
2. Prime Finish:

- a. Apply one coat of rust-resistant primer followed by a filler coat over uneven surfaces.
- 3. All equipment and metal work installed under this contract, which does not have a baked enamel or special architectural finish, and which is exposed in the hoistway, is cleaned, and painted one field coat of enamel.
- G. Glass: Laminated safety glass, minimum 9/16" thick.

2.7 OPERATION

- A. Automatic Car Stopping Zone: Stop car no more than 1/4" above or below the landing sill. Maintain stopping accuracy regardless of load in car, direction of travel, distance between landings, hoist rope slippage or stretch.
- B. Motion Control: Microprocessor-based AC variable-voltage, variable frequency with digitally encoded closed-loop velocity feedback suitable for operation specified and capable of providing smooth, comfortable car acceleration, retardation, and dynamic braking. Limit the difference in car speed between full load and no load to not more than $\pm 3\%$ of the contract speed.
- C. Power Door Operation: Open door and gate automatically when car arrives at a floor. Control door and gate closing by using constant-pressure buttons on car or at each floor. After an adjustable time period between, 30 to 120 seconds, provide audible and visible warning signal and automatically close door and gate.
- D. Nudging Operation:
 - 1. After beams of door reopening device are obstructed for a predetermined time interval, sound warning signal, and attempt to close doors.
 - 2. Activation of the door open button overrides nudging operation and reopens doors.
- E. Independent Service:
 - 1. When feature is activated from within the car, allow control of car from buttons and controls inside the car.
 - 2. Close doors by constant pressure on desired destination floor button or door close button.
 - 3. Open doors automatically upon arrival at selected floor.
- F. Emergency Power Operation:
 - 1. Where emergency power is provided to the elevator main disconnects and required by the Building Code the elevator installation shall comply with the Emergency Power Operation requirements of ASME A17.1 as modified by any superseding Building Code requirements.
 - 2. Operation is activated by a signal from an Automatic Transfer Switch (ATS) to elevator controls indicating the Emergency power source is operational.
 - a. Start and run one car in each group simultaneously at contract car speed and capacity.
 - b. Illuminate "ELEVATOR EMERGENCY POWER" signals.

- G. Firefighters' Emergency Operation: Provide equipment and operation in accordance with code requirements.
- H. Interface to Building Management Systems:
 - 1. The elevator monitoring system shall be capable of interfacing and exchanging data with third-party building management systems including Siemens, Landis AND Staefa, Johnson Controls, SCADA.
 - 2. Information shall be exchanged by Modbus protocol, open protocol or other suitable methods as required.
- I. Card/Proximity Reader Security System:
 - 1. Provide provisions inside all cars for reader unit.
 - 2. Mount reader unit as directed by Architect. Connect to card reader via traveling cable to terminal interface and relays in control room.
 - 3. Provide output signal to facilitate system tracking of floor access.
- J. Floor Lockout:
 - 1. Provide means to limit access to building floors as follows:
 - a. Individual floor lockout means in security control panel to prevent registration of car calls to any selected secure floor.
 - b. Programmable system which can limit access at certain times of the day as well as extended periods of the calendar year.
 - c. Arrange system so that independent service overrides security system.
 - d. Arrange system so that firefighters' service overrides security system.
 - e. Actuate hall lantern each time car arrives at main lobby during secure mode operation.
 - f. Provide warning light and/or signal in group control panel to indicate an attempt to register unauthorized destinations or to open car doors when car is moving or parked at a secured floor.
 - g. Provide reset switch or button to cancel warning light and signal.

2.8 MACHINE ROOM EQUIPMENT

- A. Arrange equipment in spaces shown on drawings.
- B. Geared Traction Hoist Machine:
 - 1. Single worm geared or helical geared traction type with AC induction or P.M.S.M. ACV³F motor, brakes, gear, drive shaft, deflector sheave, and gear case mounted in proper alignment on an isolated bedplate.
 - 2. Provide bedplate blocking to elevate secondary or deflector sheave above machine room floor.
 - 3. Provide hoist machine mounted direct drive, digital, closed-loop velocity encoder.
 - 4. Provide hoist machine drip pans to collect lubricant seepage.

-
5. Provide ladders and platforms with handrails and toe boards for overhead sheave access within the bounds of the machine room.
- C. Gearless Traction Hoist Machine is an acceptable option in lieu of a Geared Traction Hoist Machine for Elevators NSEF and NSHF:
6. AC induction or P.M.S.M. ACV³F gearless traction type motor with brakes, drive sheave, and deflector sheave mounted in proper alignment on a common, isolated bedplate.
 7. Provide bedplate blocking to elevate secondary or deflector sheave above machine room/equipment space floor.
 8. Provide hoist machine mounted direct drive, digital, closed-loop velocity encoder.
- D. Brake: Provide dual brakes that shall be of the self-adjusting fail-safe (spring applied and electrically released) type provided with a remotely operated, in the controller room, manual brake release and designed to meet the service factor demand of its intended use. Access panels at the top of hoistway shall not be required. Dual brakes shall operate independent of each other for ascending car over speed and unintended car movement. Provide operation to prevent the elevator from striking the hoistway overhead or unintended car movement per the requirements of Code.
- E. Solid State Power Conversion and Regulation Unit: Provide solid-state, variable voltage, variable frequency regenerative drive.
- F. Encoder: Direct drive, solid-state, digital type. Update car position at each floor and automatically restore after power loss.
- G. Controller:
1. Install equipment in the Control Room. Jamb mounted controllers are not acceptable.
 2. UL/CSA labeled.
- H. Sleeves and Guards: Provide 4" steel angle guards around cable or duct slots through floor slabs or grating. Provide rope and smoke guards for sheaves, cables, and cable slots in machine room/equipment space. Configure guards to minimize free area around cables.
- I. Machine and Equipment Support Beams:
1. Provide structural steel beams required for direct support of and attachment to building structure of hoist machine, deflector sheaves, overhead sheaves, governor, and hoist rope dead-end hitch assemblies.
 2. Provide bearing plates, anchors, shelf angles, blocking, embedment, etc., for support and fastening of machine beams or equipment to the building structure.
 3. Isolate machine and overhead sheave beams to prevent noise and vibration transmission to building structure.
- J. Governor: Friction or Centrifugal-type, car and counterweight driven with pull-through jaws and bi-directional shutdown switches. Provide required bracketing and supports for attachment to

building structure. Provide remote reset capability for all elevators to eliminate the need for any access panel in the hoistway enclosure for maintenance and testing purposes.

- K. Emergency Brake: Provide means to prevent ascending car over-speed and unintended car movement, and permanent access provisions for maintenance and repair purposes.
- L. Seismic Switch: A seismic switch shall be provided in the control room. Locate seismic switch to prevent accidental contact.
- M. Wiring:
 - 1. CSA labeled copper for factory wiring.
 - 2. Provide labels for all extra or spare wires.

2.9 HOISTWAY EQUIPMENT

- A. Guide Rails: Planed steel T-sections for car and counterweight of suitable size and weight for the application, including seismic reactions. Include brackets for attachment to building structure.
- B. Car Buffers: Oil type with blocking and support for car contract speeds exceeding 200 fpm. Spring type for speeds of 200 fpm or less.
- C. Counterweight: Steel frame with metal filler weights.
- D. Sheaves:
 - 1. Machined grooves and sealed bearings.
 - 2. Provide mounting to machine beams, car, and counterweight structural members, or building structure.
- E. Counterweight:
 - 1. Steel frame with metal filler weights.
 - 2. Provide Type “B” safety device as needed.
- F. Counterweight Guides: Spring dampened roller guides.
- G. Counterweight Runway Guard: Where counterweight is located between adjacent elevators, provide counterweight guard along entire runway next to the adjacent elevator.
- H. Seismic Equipment: Provide design, components, and operation per governing code.
- I. Governor Rope and Encoder Tape Tensioning Sheaves: Mount sheaves and support frame on pit floor or guide rail.
- J. Suspension Means: Steel Ropes or Fire-Rated, noncircular elastomeric-coated steel belt comprising of several steel cords arranged in parallel and molded within a coating.
- K. Terminal Stopping: Provide normal and final devices.

-
- L. Electrical Wiring and Wiring Connections:
1. Conductors and Connections:
 - a. Copper throughout with individual wires coded and connections on identified studs or terminal blocks.
 - b. The use of splices or similar connections in wiring except at terminal blocks, control compartments, or junction boxes is prohibited.
 - c. Provide 20% spare conductors for each wire type.
 - d. Run spare wires from car connection points to individual elevator controllers in the equipment space.
 2. Conduit:
 - a. Galvanized steel conduit, EMT, or duct.
 - b. Flexible conduit between isolated equipment, length not to exceed 3'-0".
 3. Traveling Cables:
 - a. Flame and moisture-resistant outer cover.
 - b. Prevent traveling cable from rubbing or chafing against hoistway or equipment within hoistway.
 - c. Provide five pair of shielded wires of minimum.
 - d. Provide for future CCTV provisions two pair of shielded 18-gauge wire within traveling cable from car controller to car top junction box, plus excess loop at both ends.
 - e. Provide two pair of 18-gauge wire for CCTV power.
 - f. Identify all wiring, including spares, in controls.
 4. Auxiliary Wiring: Provide conduit, wiring and connections for systems specified.
- M. Entrance Equipment:
1. Two-point hanger roller with non-metallic roller surface and suspension with eccentric upthrust roller adjustment.
 2. Bar or formed, cold-drawn removable steel door tracks with smooth roller contact surface.
 3. Door Interlocks: Operable door locks without retiring cam.
 4. Hoistway Door Unlocking Device: Provide unlocking device with pull chain under hinged, lockable cover with stainless steel No. 4 finish at all floors.
- N. Floor Numbers: Stencil paint 4" high floor designations in contrasting color on inside face of hoistway doors and hoistway fascia. Must be visible from within car.

2.10 HOISTWAY ENTRANCES

- A. Entrance Assemblies:
1. Complete entrances bearing fire labels from a certified testing laboratory approved by authority having jurisdiction.
 2. Provide entrance assemblies bearing 1-1/2hr label.
- B. Frames:
1. Bolted and lapped head to jamb assembly.
 2. Provide Numerical floor designation/Tactile marking plates:
 - a. Centered at 60" above finished floor.
 - b. Located on both side jambs of all entrances.

-
- c. Minimum 4" in height.
 - d. Tactile indications below floor designation.
 - e. Permanently fastened.
 - 3. Provide plates at main egress landing with "Star" designation.
 - C. Vertical Bi-Parting Door Panels: 12 gauge formed stainless steel plates welded into frame angles. Provide with safety astragals, vision panels, truckable sills, and load transfer angles. Provide pass-type style doors as required based on floor heights.
 - D. Sight Guards: Same material, finish, and height as hoistway entrance door panels. Construct without sharp edges.
 - E. Sills: Stainless-steel or extruded Nickel silver.
 - F. Sill Supports:
 - 1. Structural or formed steel designed to support sill load.
 - 2. Design to eliminate need for grout under the sill.
 - G. Fascia, Platform Guards and Hanger Covers: 16-gauge furniture steel with Contractor's standard finish.
 - H. Struts and Headers:
 - 1. Provide support of all entrances to building structure including connections to building structure.
 - 2. Provide door open bumpers on entrances equipped with vertical struts.
 - I. Finish of Frames and Doors: Satin finish stainless-steel.
 - J. Hoistway Access:
 - 1. Hoistway Access Switches: Mount in hall station at top floor.
- 2.11 PIT EQUIPMENT
- A. Buffers: Provide Oil type with blocking and support channels.
 - B. Pit Access:
 - 1. Hoistway Access Key Switch:
 - a. Provide key switch at lowest terminal landing.
 - b. Mount in entrance frame side jamb.
 - 2. Provide pit stop switches.
 - C. Counterweight Guard: Metal guard in pit in front of counterweight where no compensation is provided or where there is no space greater than 20 inches between the compensation means, suspension means, counterweight rails, or guards.

2.12 CAR EQUIPMENT

- A. Frame: Welded or bolted or formed steel channel construction to meet load classification specified.
- B. Safety Device: Type “B,” flexible guide clamp.
- C. Platform:
 - 1. Design and construct to accommodate load classification requirements.
 - a. Provide Class “C1” construction for freight elevators.
 - 2. The car platform consists of a steel frame with necessary steel stringers, all securely welded together.
 - 3. Isolate the passenger elevator platform.
 - a. The support frame includes rubber pads on which the platform rests.
 - b. No mechanical connections between platform and frame.
 - 4. Work Light Fixtures & AC Receptacles: Provide permanent mounted work light fixtures below platform, complete with proper lamp guards.
- D. Platform Apron: Minimum 48” high, reinforced and braced to car platform front in manufacturer’s standard finish.
- E. Cartop Guard Rail: Provide a railing system on the outside perimeter of the car top on all sides where the horizontal distance between the edges of the car top and the adjacent hoistway enclosure exceeds 12 inches.
- F. Car Guides: Roller type with three or more spring dampened, sound-deadening rollers per shoe.
- G. Finish Floor Covering: 3/8” thick steel checker plate over 3/4” thick marine plywood sub-floor.
- H. Cab Steadying Plates:
 - 1. Provide and install top of car steadying plates.
 - 2. Isolate using non-metallic guides or rollers.
- I. Power-Operated Freight Door and Gate:
 - 1. Provide means to open doors and gate from inside of car in the event of power failure.
 - 2. Closing Speeds:
 - 3. Doors: Minimum of 0.8 fps; maximum of 1.0 fps
 - 4. Gates: Minimum of 1.6 fps; maximum of 2.0 fps
- J. Car Gate: Power-operated, vertical rise, two section, minimum 6'-0" high, constructed of 12 gauge welded wire mesh welded into frame angles. Mount car gate lift chains on hoistway side of car gate. Include reversing safety edge device on gate.
- K. Door Reversing Device:
 - 1. Infrared Reopening Device:
 - a. Black fully enclosed device with full screen infrared matrix or multiple beams extending vertically along leading edge of each door panel to minimum height of 74" above finished floor.

-
2. Nudging Operation:
 - a. After door close is obstructed for a predetermined time interval (minimum 20.0-25.0 seconds), warning signal sounds, and doors close with a maximum of 2.5 foot-pounds kinetic energy.
 - b. Door open button overrides nudging operation and reopen doors.
 - L. Car Operating Panel:
 1. Vandal Resistant Fixtures.
 2. One car operating panel with faceplates for front opening and two car operating panels for front and rear opening consisting of a metal box containing the vandal resistant operating fixtures, mounted behind the car stationary front and rear return panels.
 3. Suitably identify floor buttons, alarm button, door open button, door close button and emergency push-to-call button.
 4. Pushbuttons: Provide minimum 3/4" diameter raised floor pushbuttons which illuminate to indicate call registration.
 5. Locate operating controls no higher than 48" above the car floor; no lower than 35" for emergency push-to-call button and alarm button.
 6. Earthquake indicator light jewel and audible signal.
 7. Locked Firefighters Operation Panel:
 - a. Including the following features:
 - 1) Phase II fire access switch.
 - 2) Firefighters' visual indication.
 - 3) Call cancel button.
 - 4) Stop switch, manually operated.
 - 5) Door open button.
 - 6) Door close button.
 - 7) Floors served.
 8. Provide "door open" button to stop and reopen doors or hold doors in open position.
 9. Provide "door close" button to activate door close cycle.
 10. Service Compartment:
 - a. Provide lockable service compartment with recessed flush door.
 - b. Include the following controls in lockable service cabinet with function and operating positions identified by permanent signage or engraved legend:
 - 1) Access switch.
 - 2) Light switch.
 - 3) Fan switch.
 - 4) Independent service switch.
 - 5) Constant pressure test button for battery pack emergency lighting.
 - 6) 120-volt, AC, GFCI protected electrical convenience duplex outlet.
 11. No visible manufacturer's name, logo, or other branding.
 - M. Car Top Control Station:
 1. Mount to provide safe access and utilization while standing on car top.
 2. Operating device contains Up and Down direction buttons, a Run button, an Inspection/Automatic switch and Emergency Stop switch.
 - N. Car Top Guardrails: Install car top guardrails on outside perimeter of the cab enclosure top at each side for fall protection purposes.

- O. Work Light and Duplex Plug Receptable: GFCI protected outlet at top of car. Included on/off switch and lamp guard. Provide additional GFCI protected outlet on car top for installation of car CCTV.

2.13 CAR ENCLOSURE

- A. Service Elevator: Provide complete as specified herein.
 - 1. Shell: Reinforced 10-gauge furniture steel formed panels no more than 20" wide with light-proof joints. Clad panels with stainless steel textured finish. Reinforce and brace panels to provide rigid structure and securely fasten to car sling and platform. Provide recess in car side wall for recessed mounting of car operating panels.
 - 2. Canopy:
 - a. Reinforced 12-gauge furniture steel formed panels with lockable, contacted, hinged emergency exit.
 - b. Interior finish white reflective baked enamel.
 - 3. Stationary Return Panels: Reinforced furniture steel clad with satin or textured finish stainless-steel.
 - 4. Ventilation: 3-speed blower mounted to car canopy.
 - 5. Lighting:
 - a. LED fixture flush mounted in canopy with steel guard over fixtures on car top.
 - b. Provide protective LED covers.
 - 6. Handrails/Guardrails:
 - a. Two rows.
 - b. Top handrail line minimum 1½" diameter stainless-steel grab bar with backing plates and captive nuts.
 - c. Lower guardrail line 8" x 3/8" solid stainless-steel flat stock bars mounted on both sides and rear of the car, where applicable.
 - d. Return handrail/guardrail ends to car walls.
 - 7. Pads and Buttons covering side and rear walls and adjacent front returns.

2.14 HALL CONTROL STATIONS

- A. Pushbuttons:
 - 1. Vandal Resistant construction.
 - 2. Include pushbuttons for each direction of travel that illuminate to indicate call registration.
 - 3. Include engraved message and pictorial representation prohibiting use of elevator during fire or other emergency as part of faceplate or on separate engraved plate.
 - 4. Pushbutton design matches car operating panel pushbuttons.
 - 5. Provide vandal resistant pushbutton and light assemblies.
 - 6. Provide LED illumination.
 - 7. Provide Phase I Fire Service key switch, engraved operating instructions and illuminating jewel.
 - 8. Provide communication check failure indication and silence key switch.
 - 9. Provide illuminating jewels indicating standby power status.
 - 10. Incorporate all items required by Code at the primary egress level into a single hall fixture.

2.15 SIGNALS

- A. Car Position Indicator:
 - 1. Alpha-numeric digital indicator containing floor designations and direction arrows a minimum of 2" high to indicate floor served and direction of car travel.
 - 2. Locate fixture in above each car operating panel.
 - 3. Illuminate proper direction arrow to indicate direction of travel.
- B. Hall Position Indicator: Alpha-numeric digital indicator containing floor designations and direction arrows to indicate floor served and direction of car travel. Mount integral with hall control stations at all floors.
- C. Fixture Faceplate Material and Finish:
 - 1. Stainless-steel all fixtures.
 - 2. Tamper resistant fasteners for all public facing fastenings.
- D. Floor Passing Tone: Provide an audible tone of no less than 20 decibels and frequency of no higher than 1500 Hz, to sound as the car passes or stops at a floor served.
- E. Voice Synthesizer: Provide electronic device with easily reprogrammable message and female voice to announce car direction, floor, emergency exiting instructions.

2.16 COMMUNICATION

- A. Car Communication System:
 - 1. Hands-Free Phone System: Two-way communication instrument in car with automatic dialing, tracking, and recall features. Provide wireless 5G/LTE connectivity. System must be approved by the Port of Seattle, Facilities and Infrastructure team.
 - 2. **[DESIGN TEAM TO CONFIRM WIRELESS 5G/LTE CONNECTIVITY IS AVAILABLE. ALTERNATE IS ANALOG PHONE SERVICE.]**
 - 3. Emergency Personnel Communication:
 - a. Communication system is provided allowing emergency personnel to establish communications with each elevator individually.
 - b. On the same car operating panel as the phone push button, provide capability to communicate with and obtain responses from passengers.
 - c. Speaker volume must be tested and approved by the Port of Seattle, Facilities and Infrastructure team.
 - d. Provide display video capability for entrapment assessment.
 - 4. Communication for Deaf, Hard of Hearing and Speech Impaired:
 - a. On the same car operating panel as the phone push button, provide capability to communicate visually with and obtain responses from passengers, including those passengers who cannot communicate verbally or hear.
 - b. Minimum screen size of 6" for visual display.
 - c. Provide shielded twisted pair wiring to communicate to control room.
 - d. Device shall be open-sourced and capable of being monitored by any entity as selected by the owner. All software, hardware, and training cost associated with the

device shall be included within this project. Associated monthly monitoring costs will not be accepted.

5. Intercom System:
 - a. General:
 - 1) Provide intercommunication system complete with talkback speaker, required auxiliary equipment and wiring.
 - 2) Intercom volume must be tested and approved by the Port of Seattle, Facilities and Infrastructure team.
 - 3) A battery backup system is provided for the two-way conversation system.
- B. Remote Monitoring:
 1. Provide 24-hours per day, 7-days per week. System to capture faults or system shutdowns in real-time occurrence. System must be approved by the Port of Seattle, Facilities and Infrastructure team.
- C. Communicate faults or shutdowns to reception system, enabling automatic dispatch of technicians. Elevator Management System and Information:
 1. General: **[DESIGN TEAM TO CONFIRM WIRELESS 5G/LTE CONNECTIVITY IS AVAILABLE. ALTERNATE IS ANALOG PHONE SERVICE.]**
 - a. Utilizing wireless 5G/LTE connectivity, each controller provides an extensive list of output information, including data logging, fault logs operational events, performance information including car speed, floor to floor times, and door times.
 - b. The system is real time, capable of driving remote monitors or computer terminal systems connected via Intranet system, that continually display the status of each car and call.
 2. The system displays all units in a group and separate units on one screen in a graphical format and record the following information for each monitored unit:
 - a. Group status.
 - b. Individual car status with expandable menus.
 - c. Service Driven Outages.
 - d. Maintenance Activity Indicators.
 3. Faults monitored with visual and audible alarm, triggered by combinations of any of the above status points.
 - a. Transmit email when any monitored faults occur.

2.17 FIREFIGHTERS' CONTROL PANEL

- A. Firefighters' Control Panel:
 1. Locate in building fire control room or as directed by Contractor.
 2. Fixture faceplate, stainless-steel, satin finish, includes the following features:
 - a. Car position and direction indicator, digital-readout, or LCD flat screen color monitor.
 - 1) Identify each position indicator with car number and group identification.
 - b. Indicator showing operating status of car.
 - c. Manual car standby power selection switches and power status indicators.
 - d. Two-position firefighters' emergency return switches and indicators with engraved red filled instructions.

- e. Floors served
 - f. Designate FSAE elevators.
 - g. Identify all indicators and manual switches.
- 3. Provide wiring to control panel.
 - a. Coordinate size and location of conduit with Contractor.
- B. Firefighters' Key Box:
 - 1. Flush-mounted box with lockable hinged cover.
 - 2. Engrave instructions for use on cover per Local Fire Authority requirements.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Prior to beginning installation of equipment examine hoistway and control room areas.
- B. Verify no irregularities exist that affect execution of work specified.
- C. Verify electrical power location and characteristics in coordination with equipment requirements.
- D. Do not proceed with installation until work in place conforms to project requirements.

3.2 INSTALLATION

- A. Install all equipment in accordance with Contractor's instructions, referenced codes, specification, and approved submittals.
- B. Install control room equipment with clearances in accordance with referenced codes and specification.
- C. Install all equipment so it may be easily removed for maintenance and repair.
- D. Provide any required hoisting/safety beams.
- E. Install all equipment to afford maximum accessibility, safety, and continuity of operation.
- F. Clean all architectural finishes and replace or restore any surfaces damaged during construction to like new condition.

3.3 FIELD QUALITY CONTROL

- A. Acceptance Testing: On completion of elevator installation and before permitting elevator use (either temporary or permanent), perform acceptance tests as required and recommended by ASME A17.1/CSA B44 and by governing regulations and agencies.

3.4 CONSTRUCTION TOLERANCES

- A. Install rails plumb and align vertically with tolerance of 1/16" in 100'-0".
- B. Secure joints without gaps and file any irregularities to a smooth surface.

3.5 ADJUSTING

- A. Static balance car to equalize pressure of guide shoes on guide rails.
- B. Dynamically balance car and counterweight.
- C. Lubricate all equipment in accordance with Contractor's instructions.
- D. Adjust motors, power conversion units, brakes, controllers, leveling switches, limit switches, stopping switches, door operators, interlocks, and safety devices to achieve specified performance levels.

3.6 CLEANING

- A. Keep work areas orderly and free from debris during progress of project.
- B. Remove packaging materials on a daily basis.
- C. Remove all loose materials and filings resulting from work.
- D. Clean Control room equipment and floor.
- E. Clean hoistways, car, car enclosure, entrances, operating and signal fixtures.
- F. Clean pit equipment and floor.

3.7 DEMONSTRATION:

- A. Engage a factory-authorized service representative to train Owner's maintenance personnel to operate all aspects of elevators while in normal operation.
- B. Determine that operation systems and devices are functioning properly.

3.8 PROTECTION

- A. Temporary Use: Comply with the following requirements for each elevator used for construction purposes:
 - 1. Provide car with temporary enclosure, either within finished car or in place of finished car, to protect finishes from damage.

2. Provide strippable protective film on entrance and car doors and frames.
3. Provide padded wood bumpers on entrance door frames covering jambs and frame faces.
4. Provide other protective coverings, barriers, devices, signs, and procedures as needed to protect elevator and elevator equipment.
5. Do not load elevators beyond their rated weight capacity.
6. Engage elevator Installer to provide full maintenance service.
 - a. Include preventive maintenance, repair, or replacement of worn or defective components, lubrication, cleanup, and adjustment as necessary for proper elevator operation at rated speed and capacity.
 - b. Provide parts and supplies which are the same as those used in the manufacture and installation of original equipment.
7. Engage Elevator Installer to restore damaged work, if any, so no evidence remains of correction.

END OF SECTION 14 21 13