




3/4" = 1' 

### KEYED NOTES:

- ① REMOTE FAULT INDICATOR TO BE PLACED ON SIDE OF SECTIONALIZING CABINET OPPOSITE THE PMI SWITCH  
⚠ UNLESS DIRECTED OTHERWISE, SCHWEITZER PART NUMBER 3CRL-0800-IRACC OR APPROVED EQUAL. ADD 'W' TO PART NUMBER FOR TAMPER PROOF WINDOW KIT.
- ② XXX = SWITCH VAULT OR MANHOLE NUMBER  
YYY = FEEDER NUMBER
- ③ FASTEN CONTROL CABLES TO THE BACK OF THE ENCLOSURE WITH ADHESIVE TY-RAP ANCHORS AND TY-RAPS.
- ④ MOUNT FAULT INDICATOR PER MANUFACTURERS RECOMMENDATIONS. REFINISH EXPOSED STEEL EDGES OF HOLES TO MATCH THE EXISTING FINISH.




### SECTION

600A ELBOW TERMINATION AT SECTIONALIZING CABINET

SCALE: 3/4" = 1'-0"

3



### DETAIL

ONE-LINE DIAGRAM OF SECTIONALIZER

SCALE: N/A

3



DESIGNED BY	DATE
JAS	6/25/03
DRAWN BY	DATE
JAS	6/25/03
CHECKED BY	DATE
APPROVED BY	DATE

DETAIL:

STIA, F&I STANDARD DETAILS  
SECTIONALIZING CABINET DETAILS  
FAULT INDICATORS

REVISION:

DESCRIPTION:

STD: 261800

1

02